

# TAYLOR-SEIDENBACH, INC.

FAX (504) 486-7477

PHONE (504) 486-7474

FIBERGLASS PRODUCTS -- ROOFING AND INSULATION -- HVAC PRODUCTS

AIR FILTERS -- FIRE STOP CAULKS -- ACCESS PANELS

May 17, 2010



## Round Diffuser Damper (RCD) and Controls

ROUND DIFFUSER DAMPER & CONTROLS				
DIA.	MODEL			PRICE
6"	RCD6			\$xx.xx
7"	RCD7			\$xx.xx
8"	RCD8			\$xx.xx
9"	RCD9			\$xx.xx
10"	RCD10			\$xx.xx
12"	RCD12			\$xx.xx
	RMRC	REPLACEMENT MOTOR FOR RCD		\$xx.xx
	OSL	OCCUPANCY SENSOR		\$xx.xx
	MWC	MANUAL WALL CONTROL		\$xx.xx



Manual Wall Control



Occupancy Sensor

# **TAYLOR-SEIDENBACH, INC.**

FAX (504) 486-7477

PHONE (504) 486-7474

FIBERGLASS PRODUCTS -- ROOFING AND INSULATION -- HVAC PRODUCTS  
AIR FILTERS -- FIRE STOP CAULKS -- ACCESS PANELS

1) A Manual Wall Control (MWC) can be wired directly to the damper. The occupant can use the switch to incrementally adjust the damper setting.

2) An Occupancy Sensor (OSL) can be wired directly to the damper. As someone enters the space and turns on the lights, the sensor detects the lights being turned on and opens the damper to the pre-set occupied airflow setting. When the lights are turned off the sensor reacts and sets the damper to its minimum (vacant) setting.